

## SRM CADENCE MAGNET ADDITIONAL INFORMATION

[www.srm-power.co.uk](http://www.srm-power.co.uk)

Due to varying frame designs and BB shell sizes, two styles of cadence are available from SRM; these rare earth magnets are very strong and should cover the setups on most frame styles.

The longer magnet is best used if your magnet is positioned closer to the center point of the BB (lower to mid-point on the backside of the PowerMeter).



If you have a larger BB shell that places the magnet further from the center point of the BB (on the outer edge of the back side of the PowerMeter), the smaller magnet can be used.



With both setups the magnet should be placed 2-3mm away from the backside of the PowerMeter for optimal and consistent cadence detection.

If you are having difficulty obtaining cadence, try both magnets in varying height and distance until consistent cadence is detected by the PowerControl or head unit.

For more information see [www.youtube.com/user/SRMUSA/videos](http://www.youtube.com/user/SRMUSA/videos) or contact customer service at:  
01953 711176 (info@srm-power.co.uk)